

OBJECT: PROPER POWER OFF OF THE DIAGNOSTIC EQUIPMENT SOCIO 500 and POKAYOKE

FROM: CUSTOMER SERVICE DEPARTEMENT

TO: DEALERS and USERS



With the following Technical Note we would like to remind you the right procedure for powering off the Diagnostic Equipment:

1. Press the 'F' key of the Equipment Keyboard.



2. By means of the vertical arrow keys, select the 'Tool switch off' option and confirm by using the Enter key.



3. Upon the next message visualized on the display, confirm by using the Enter key one more time.



**DO NOT** power off the Diagnostic Equipment by means of the Power-on key.

In order to **POWER OFF** properly the Diagnostic Equipment you must always follow the procedure above described.